

Passport[®] Guide DVR

Quick Reference Guide

Arris

Version 7.3





Digital cable the way it was meant to be

It's time to discover digital cable the way it was meant to be—television you can enjoy with tremendous convenience, variety, and control.

Search fast. Save time. Record programs with ease. Find the shows you want to watch, and watch them when you want.


It's time to optimize your TV experience. Spend less time looking for something to watch. Spend more time watching something great!

Time Grid

Passport Guide DVR's easy-to-use Time Grid helps you find shows in seconds. Just press the GUIDE key on your remote to display up to 2.5 hours of program listings for seven channels at a time. Use the arrow keys to navigate the grid.

Press the GUIDE key again to search for shows by title or keyword, filter listings by channel or theme, or display the Discovery Dashboard.


Press the A key to sort or list programs that appear on your favorite channels, or to list only HD programs, or programs from custom lists that you create.



Press GUIDE twice to search.

Find Shows

Find exactly what you want to watch. Press the GUIDE key twice to begin a search for shows by title or keyword; to filter listings by channel or theme; or to display the Discovery Dashboard. You can quickly find programs starring a favorite actor, or about a topic of special interest. You can also display a listing of all of your recorded shows.



Press INFO from the Time Grid.

Program Info



With the Time Grid displayed, press the INFO key to access Plot Summary, Cast & Crew, and You Might Like options.

The Cast & Crew option displays the names of associated actors and enables you to schedule DVR recordings that feature them. You can also display listings of recommended shows you might like to watch.

Dashboard Navigation

Once you select a title on the Dashboard, you can do the following :

- Press INFO for more information.
- Press B to buy.
- Press PLAY to play a preview.
- Press SELECT/OK to watch a purchased movie.



Press INFO twice to browse.

Browse

Press the INFO key once to display information about the program you are currently watching. Press the INFO key twice to display a brief program description. Use the arrow keys to browse other channels and times without leaving the show you're currently viewing.

General Settings

Press the MENU key twice to begin to personalize your television experience.

You can adjust settings for My Preferences, Parental Controls, Timers, Purchase Locks and PINs, and more.



Press MENU twice to access the General Settings.

DVR


DVR¹ puts you in control. You can pause live television. Rewind and replay programs in an instant. With DVR, you can build your own personal library of programs, movies, sports, and other shows to watch on your schedule.




With DVR, you can pause live TV, re-run an instant replay, and even rewind or fast-forward video or live TV.

- ▶ Play
- ⏸ Pause Live TV
- ↺ Instant Replay
- ⏩ Fast-Forward (3 speeds)
- ⏮ Rewind (3 speeds)
- LIVE Return to Live TV


Set your DVR to record a show or an entire series right from the Time Grid. Press REC on your remote to record.



Press the DVR/LIST key to display a list of your recorded shows (above). Highlight a program, then press SELECT/OK to play. Press DVR/LIST again to manage series or scheduled recordings, etc.



Lost & Found lets you recover² deleted shows. You may also be able to see why certain programs failed to record. Press DVR/LIST while the Recorded Shows screen is displayed to access the Lost & Found.



1-On Demand and DVR not available in all areas. On Demand programs may not be recorded with DVR.

2-Based on available hard disc space and other restrictions.

Don't just watch TV. Experience it with Passport Guide DVR.